

Economic type,

Professional IPC Quick Start Guide



2 Appearance & interface Instructions




Network camera network access, power DV12V access, network pass after 30 seconds

Note: Plug-ins need to be installed if you login via IE browser. IE is default to intercept plugin. Please set IE security level. Go to <internet options>--<security>--<Customized Level>--<ActiveX >, enable them all. Or go to our official website to download and install plug-ins (<http://www.xmeye.net>); Or install IE plug-in _Vx.x.x.xx.exe via CD.

8.3 Mobile Access
Network environment:wifi,3G
Mobile system:Android, Apple
Software Name:VmEyeSuper
Software Download:Google Market, app store
Note:When the device can access to the public network,you can realise public network monitoring via VmEyeSuper.

(3) Click login to enter cloud service interface, as follows:



(4) After successful configuration, wherever and whenever you are, as long as you can surf the Internet ,you can get access to the device.

PC monitoring:Login <http://www.xmeye.net>; Login with user name and password (user name:guest password:123).

(5) Device list is on the left, click the device the preview.

4.2 Mobile Access
Network environment:wifi,3G
Mobile system:Android, Apple
Software Name:VmEyeCloud Lite
Software Download:Google Market, app store

1 Statement

Thank you for purchasing our products, if you have any questions or needs, please feel free to contact us, this manual applies to the full range of professional network cameras. This manual is applicable for Economic type which also works for other channels.

Only a few instructions for product operations are included, for more information, please read the CD.


Any enhancement in product features shall be added into the manual consistently without further notice.

3 LAN Access

When connected to the network, login DVR to start remote monitoring via IE browser

3.1 IPC connection
Open IE browser, enter IP address, take 192.168.1.20 as an example, input <http://192.168.1.20> to connect.


3.2 IPC login
Enter user name and password. (default user name is admin, no password). Change the administrator password timely after login, as follows:



4 Public network access (cloud operation)

Cloud technology realises one step on the Internet, which greatly facilitates the customers in public network monitoring. For first use, please start here. If not, just skip.

4.1 PC access
(1) Enter <http://xmeye.net> to login.



(2) Install step by step according to the guides.



5 Product warranty card

Product Name		Model	
Purchase Date		Distributor	
Purchase Place			
Customer Name		Occupation	
Tel		Post Code	
Company			
Address			

Design and specifications are subject to change without notice.